

Rules for Operation of Dunk Tank

1. **Do not go over 45 mph when towing.**
2. **NEVER** operate Dunk Tank around electricity.
3. Must have adult supervision to operate dunk tank.
4. Water level in tank should be kept at least 6" from top of tank.
5. Only one person allowed on seat or in the tank at a time.
6. Check that seat is secured prior to placing full weight on seat.
7. Always drain the tank when not in operation or is unattended.
8. **NEVER** stand on the seat.
9. Caution: Participant needs to sit up straight; keep hands on lap; keep legs together.
10. **NEVER** allow participant to hold on to bars or stick feet through bars.
11. Operator only permitted behind tank or target area.
12. Persons who have used drugs or alcohol are **NOT** permitted in tank.
13. Maximum weight limit is 250 pounds.

DIRECTIONS FOR TRANSPORT

Lay tank down, slide trailer hitch into the two receivers and put in the two hitch pins. Attach safety chains to auto, and make sure that lug nuts are tight before pulling.

A 2" ball hitch is required for towing.



DIRECTIONS FOR SET-UP

1. Unwrap target frame (tarp frame) and attach tarp to frame with the yellow rope that is included (the longer rope is for the large part tarp). Do not over tighten rope. Balls should not bounce back if tarp is correct.
2. Bolt aluminum cage to tank using 3/8" x 2" bolts. Bolts to attach cage to tank frame are in tank frame. Attach target frame to tank frame using Hinge Pins and Cotter Pins.
3. The target arm goes behind the bar under the seat; the bolt goes into bolt hole on frame and then goes through the hole allowed in the tarp. Then attach the round target from the front.
4. Chain holds target back to keep frame from blowing into target when windy. You will see two eyelets to connect the chain to on the backside of the frame and on the trailer frame.

